




구분	관리번호	부품번호	부품명
1	379-4188	8000002241	Left And Right Housing
2	379-4189	8000002242	Knob Assembly
3	379-4190	8000002243	Back Cover
4	379-4191	8000002244	Shaft Ring
5	379-4192	8000002245	PCB Board
6	379-4193	8000002246	Screw
7	379-4194	8000002247	Motor Assembly
8	379-4195	8000002248	Screw
9	379-4196	8000002249	Fan Cover
10	379-4197	8000002250	Front Cover
11	379-4198	8000002251	Heat Gun Can Cover
12	379-4199	8000002252	Heating Element Assembly
13	379-4200	8000002253	Switch PCB Assembly
14	379-4201	8000002254	Switch Cover
15	379-4202	8000002255	Screw
16	379-4203	8000002256	Cord Guard
17	379-4204	8000002257	Screw
18	379-4205	8000002258	Cording Bushing
19	379-4206	8000002259	Power Cord & Plug
20			Label